




Safety and operating manual

Belt Sander JCB-BS950



ORIGINAL INSTRUCTIONS

GENERAL POWER TOOL SAFETY WARNINGS



WARNING! Read all safety warnings and all instructions.

Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your electric (corded) power tool or battery-operated (cordless) power tool.

1. Work area safety

- a) **Keep work area clean and well lit.** Cluttered or dark areas invite accidents.
- b) **Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
- c) **Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

2. Electrical safety

- a) **Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with grounded power tools.** Unmodified plugs and matching outlets will reduce risk of electric shock.

- b) **Avoid body contact with grounded surfaces, such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is grounded.

- c) **Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.

- d) **Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool.** Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.

- e) **When operating a power tool outdoors, use an extension cord suitable for outdoor use.** Use of a cord suitable for outdoor use reduces the risk of electric shock.

- f) **If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply.** Use of an RCD reduces the risk of electric shock.

3. Personal safety

- a) **Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** A moment of inattention while

operating power tools may result in serious personal injury.

b) Use personal protective equipment. Always wear eye protection. Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.

c) Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.

d) Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.

e) Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.

f) Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.

g) If devices are provided for the connection of dust extraction and

collection facilities, ensure these are connected and properly used. Use of dust collection can reduce dust-related hazards.

4. Power tool use and care

a) Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.

b) Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.

c) Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.

d) Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.

e) Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation.

If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.

f) Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.

g) Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.

5. Service

a) Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.

SAFETY WARNINGS FOR BELT SANDER:

Hold power tool by insulated gripping surfaces, because the belt may contact its own cord. Cutting a "live" wire may make exposed metal parts of the power tool "live" and could give the operator an electric shock.

SYMBOLS



To reduce the risk of injury, user must read instruction manual



Wear ear protection



Wear eye protection



Wear dust mask




Double insulation



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authorities or retailer for recycling advice.

COMPONENT LIST



1. AUXILIARY HANDLE
2. LOCK-ON BUTTON
3. HAND GRIP AREAS
4. DUST BAG
5. BELT COVER
6. BELT CENTERING CONTROL KNOB
7. ON-OFF SWITCH
8. DUST EXTRACTION OUTLET
9. VARIABLE SPEED CONTROL DIAL
10. SANDING BELT LEVER
11. ROTATION DIRECTION ARROW
12. SANDING BELT (See D)*
13. SANDING PLATE (See E)

*Not all the accessories illustrated or described are included in standard delivery.

TECHNICAL DATA

Voltage	220-240V~50Hz
Power input	950W
No load speed	240-350m/min
Belt size	76X533mm
Sanding size	76X130mm
Protection class	□ /II
Machine weight	3.4kg

NOISE INFORMATION

A weighted sound pressure L_{pA} : 83dB(A)

A weighted sound power L_{wA} : 94dB(A)

K_{pA} & K_{wA} = 3.0dB(A)

Wear ear protection when sound pressure is over: 80dB(A) 


VIBRATION INFORMATION

Vibration total values (triax vector sum) determined according to EN 60745:	
Typical weighted vibration	Vibration emission value $a_h = 6,85m/s^2$
	Uncertainty $K = 1.5m/s^2$



WARNING: The vibration emission value during actual use of the power tool can differ from the declared value depending on the ways in which the tool is used dependant on the following examples and other variations on how the tool is used:
How the tool is used and the materials being cut or drilled.
The tool being in good condition and well maintained.
The use the correct accessory for the tool and ensuring it is sharp and in good condition.
The tightness of the grip on the handles and if any anti vibration accessories are used.
And the tool is being used as intended by its design and these instructions.

This tool may cause hand-arm vibration syndrome if its use is not adequately managed.

 **WARNING:** To be accurate, an estimation of exposure level in the actual conditions of use should also take account of all parts of the operating cycle such as the times when the tool is switched off and when it is running idle but not actually doing the job. This may significantly reduce the exposure level over the total working period.

Helping to minimise your vibration exposure risk.

ALWAYS use sharp chisels, drills and blades.

Maintain this tool in accordance with these instructions and keep well lubricated (where appropriate).

If the tool is to be used regularly then invest in anti vibration accessories.

Avoid using tools in temperatures of 10°C or less.



Plan your work schedule to spread any high vibration tool use across a number of days.

ACCESSORIES

Dust bag	1
Sanding Belt	1

We recommend that you purchase your accessories from the same store that sold you the tool. Use good quality accessories marked with a well-known brand name. Choose the type according to the work you intend to undertake. Refer to the accessory packaging for further details. Store personnel can assist you and offer advice.

OPERATING INSTRUCTIONS



NOTE: Before using the tool, read the safety and operating manual carefully.

INTENDED USE

The machine is intended for dry sanding - with high removal capacity - of wood, plastic, metal, filler as well as varnished surfaces.

1. ON/OFF SWITCH

Depress to start and release to stop your tool.

2. SWITCH LOCK-ON BUTTON (See A)

Depress on/off switch (7) then lock on button (2). Your tool is now locked on for continuous use. To switch off your tool just depress and release the on/off switch.

3. VARIABLE SPEED CONTROL DIAL (See B)

Adjust the variable speed control dial (9) to increase or decrease the speed according to the material and sanding belt specification to be used (also possible during no load operation). See the table below for general guidance on speed selection. Avoid prolonged use at very low speed as this may damage your sander's motor.

Material	Speed selection	Belt grit
Solid wood	5-6	80
Veneer	2-4	150
Chipboard	1-5	60/80
Plastics	2-5	100
Steel	5-6	80
Paint removal	6	40/60
Balsa wood	1-3	100
Acrylic	1-2	100

4. HAND GRIP AREAS (See C)

Always hold your belt sander firmly with both hands when operating.

5. CHANGING A SANDING BELT



⚠ WARNING! Remove the main plug from the socket before changing sanding belt.


Pull the lever (10) to release the belt tension. Remove and fit a new belt over both rollers (See D). Ensure the direction of rotation arrows on the belt and the sander are the same. Close the lever to tension the belt.

6. BELT CENTERING CONTROL


⚠ WARNING! Wear eye protection before carrying out a belt centering adjustment.

Turn the machine upside down, hold it firmly with one hand, start the motor and release the switch immediately after observing tracking of sanding belt. If abrasive belt runs outward, turn tracking






adjustment knob counter-clockwise and clockwise if belt runs inward (See E). Adjust the belt until the outer edge of the belt is even with the outer edge of the base-plate (13). Belt life will be greatly increased by keeping the tracking adjustment set properly.



7. DUST BAG (See F)

You must use the dust collection bag provided to collect the dust produced during sanding. The dust collection bag plastic bracket slides down onto the dust outlet on the belt sander. When the dust collection bag is full, remove and empty by opening the zip on the dust bag (4).



8. DRIVE BELT REPLACEMENT (See G)

⚠ WARNING! Remove the main plug from the socket before carrying out a drive belt replacement. Remove the three screws (a) and the belt cover as shown. Carefully cut the drive belt if not already broken and remove from your belt sander. Fit your new drive belt around the large pulley. Then install onto the small pulley by rotating clockwise and pushing the drive belt shown around the small pulley at the same time. The drive belt will be a tight fit. Fit the belt cover and three screws.

WORKING HINTS FOR YOUR BELT SANDER

If your power tool becomes too hot, especially when used at low speed, set the speed to maximum and run with no load for 2-3 minutes to cool the motor. Avoid prolonged usage at very low speed. Always use a sanding belt suited to the material you wish to sand. Always ensure the work-piece is firmly held or clamped to prevent movement. Support large panels close to the sanding area. Any movement of the material may affect the quality of the sanding finish. Start your sander before sanding and turn off only after stopping sanding. For best results sand wood in the direction of the grain. Do not start sanding without the sanding belt fitted. Empty the dust bag every 5 minutes or sooner to ensure efficient dust collection.

MAINTENANCE

Remove the plug from the socket before carrying out any adjustment, servicing or maintenance.

Your power tool requires no additional lubrication or maintenance. There are no user serviceable parts in your power tool. Never use water or chemical cleaners to clean your power tool. Wipe clean with a dry cloth. Always store your power tool in a dry place. Keep the motor ventilation slots clean. Keep all working controls free of dust. Occasionally you may see sparks through the ventilation slots. This is normal. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

ENVIRONMENTAL PROTECTION



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authorities or retailer for recycling advice.

WARRANTY STATEMENT

A product of hard work

In every corner of the world you'll find a JCB machine. Since our beginnings in 1945, we have always invested heavily in research and development, keeping JCB at the cutting edge of innovation. Today, JCB has some of the finest engineering facilities across the globe, producing a range of over 300 machines and maintains a reputation for unrivaled customer service. The same innovation to always get the job done better, the same quality to never let you down, the same engineering heritage and expertise that you can trust, can be found in JCB Power Tools. JCB power tools are guaranteed against manufacturing defects for a period of 3 years from the date of purchase.

If your JCB power tool becomes defective within this warranty period, we guarantee to:

- Replace or repair all defective parts, free of charge, or
- Repair products free of charge, or
- Replace the unit with a new or re-conditioned unit, free of charge.

Conditions

Your 3 year guarantee does not cover defects caused by or resulting from:

- overload, misuse, or neglect
- normal wear and tear, including accessory wear
- hire use
- repairs attempted by anyone other than an authorised agent
- damage caused by foreign objects, substances or accidents

Your 3 year guarantee does not cover:

- battery packs as they are guaranteed for a 12 month period
- accessories supplied with the power tool.

Warranty claims

For guarantee claims, please contact JCB Customer Services. You will be required to submit proof of purchase.

JCB CUSTOMER HELPLINE 0333 0143092

Terms

This guarantee does not affect your statutory rights. JCB SO53 3LE (Registered in England under No. 973387).

EC DECLARATION OF CONFORMITY

We,
Positec Power Tools (Europe) Ltd
PO Box 6242, Newbury, RG14 9LT, UK

Declare that the product

Description

JCB Belt Sander

Type

(JCB-BS950)

Function

Removing surface material using an abrasive medium

Complies with the following Directives,

EC Machinery Directive

2006/42/EC

EC Electromagnetic Compatibility Directive

2014/30/EU

RoHS Directive

2011/65/EU

Standards conform to

EN 60745-1

EN 60745-2-4

EN 55014-1

EN 55014-2

EN 61000-3-2

EN 61000-3-3

The person authorised to compile the technical file,

Name: Russell Nicholson

Address: Positec Power Tools (Europe) Ltd

PO Box 6242, Newbury, RG14 9LT, UK



Suzhou 2016/01/11

Allen Ding

Deputy Chief Engineer, Testing & Certification

